




Voesh Midi Controllers driver problem


Connect the MX to the computer.

Does it make sound when connecting/disconnecting? *(it should)*

Right Click on the windows icon and select Device Manager




Does it show USBasp with an ! Exclamation?




If so install the driver again (located in the map *manual and driver*).

Make sure **USBasp** and **libusb-win32** are selected.



If **USBasp** isn't in the dropdown list, enable **List All Devices** in the Options Menu.

After installing, it should look like this, without a ! exclamation.



If this doesn't help, then if possible, try another computer.

Last resort: In the directory "**Bin**" run "**drivertest.bat**".

Mail the result at voesmidicontrollers@gmail.com