



# Voes MX Installation Guide

## Windows

Download the latest editor, driver, firmware and manual on [voes.be/downloads](https://voes.be/downloads).

Unzip the file.

Connect the **MX** to your computer (Windows 7 or higher).


Let Windows detect the device (it will report driver not found). If a window pops up asking to search for driver, just close it or click *Cancel*.

Run **Voes MX-driver** (located in the map *manual and driver*). Do not update if asked.

Make sure **USBasp** and **libusb-win32** are selected. (If **USBasp** is not in the dropdown list, enable **List All Devices** in the Options Menu.)

Start **Voes MX-editor**.


If you get an error, check the *Voes Driver Problem* document (located in the folder *manual and driver*).



## Mac

Download the latest editor, firmware and manual on [voes.be/downloads](https://voes.be/downloads).

Unzip the file and open the editor. If Mac OS blocks it, you need to unblock this. Open **System Preferences**, select **Security & Privacy** and click **Open Anyway**.



That's it. Now you can Read and Write from/to your MX.